




Commissioning & Operation

Mounting the Printer	2	Creating a print job	13
Unpacking the 64-xx	2	Transferring a print job	13
Carrying the 64-xx	4	Using CompactFlash cards	15
Mounting the 64-xx	5	Setting the realtime clock	16
Printer connections	6	Outputting the realtime clock value using Easy Plug	16
Control panel (display)	8	Starting to print	17
Operating modes	9	Settings for the material type	17
Basic Operating Procedures	10	Printing the status report	17
Connecting the printer	10		
Setting the interface	11		
Offline operation	11		
Online operation	12		

Mounting the Printer

Unpacking the 64-xx

1. Lift off the lid of the shipping box [1].
2. Take out the plastic bag containing the accessories [1B].
3. Lift off the styrofoam support [1A].



- [1] Shipping box without lid:
A Styrofoam support
B Accessories

4. Part the plastic cover [2].



WARNING!

Printers with mounted cutter: The cutter may cause cut injuries.

- Do not grasp the cutter [3A] as a handle.
- Use the cutter motor [3B] as a handle.




- [3] Don't use the cutter as a handle!

5. Grab the printer from underneath and lift it out. The material feed slot in the back wall of the printer [3A] can be used as a handle.

- ▮ Printers with mounted cutter: The motor [3B], but *not* the cutter [3A] may be used as a handle!



- [2] Part the plastic cover...



- [4] ... and lift the printer out of the box.
A Back wall of printer (not visible)
B Front cover (do not use for lifting)
C Rubber feet



CAUTION! - Do not lift the printer by the front cover [4B]. The front cover is a movable part not designed for handling stress.

6. Place the printer on a level surface in its usual operating position (rubber feet [4C] at the bottom).
- ▣▣▣▣▶ The *original packaging* should always be used for transporting the printer!

Carrying the 64-xx



WARNING!


The 64-xx is a heavy printer. The weight depends on the printer type and equipment and can vary from 20 kg (64-04/05) up to 29.5 kg (64-08 Dispenser).

A bad carrying technique can cause back injury.

- Try to lift the printer in a safe way, for example by
 - carrying it close to your body, and by
 - bending your knees, not your back.
- To carry the printer, put one hand under the base plate and the other into the feed slot at the back of the printer.



CAUTION! - Do not lift the printer by the front cover (window side), as this can damage it!



[5] Carrying the 64-xx safely (A: back – grab by the feed slot, B: front – grab by the base plate).

Mounting the 64-xx

The 64-xx has been designed as a desktop printer, which means that it is normally mounted in an upright position on a table [2]. Other sufficiently large, level and sturdy surfaces can also be used as a base.



WARNING!

When choosing a base for the printer, observe the following guidelines to avoid dangerous operating conditions:

- The base needs to be at least as deep and wide as the printer itself.
- The surface needs to be level, solid and dry.
- The printer's fan and ventilation slits must not be obstructed, as the device may overheat otherwise.
- The printer must not be mounted in the immediate vicinity of other heat sources.
- The environmental conditions specified (temperature, air humidity, etc.) need to be complied with.
- The power cable should be run to the printer so that
 - nobody will trip on it, and that
 - the power plug can easily be pulled out if necessary.



[6] The correct orientation of the 64-04.


Printer connections



CAUTION!

Add-on devices of an inferior quality may damage the printer!

- Connect the printer only to devices that fulfil SELV (safety extra-low voltage) circuit requirements acc. to EN 60950!
- Only connect OEM devices.



[7] Back of the 64-xx with the following options installed: USI board (H), connector for external operation panel (I) and start/stop signal input (J).

- A** *Card slot*
For SD/MMC cards; is not yet supported
- B** *Card slot*
For CompactFlash cards; used for storing fonts, logos, graphics, etc.
- C** *USB interface type A (host)*
For transfer of print data
- D** *2x USB interface type B (device)*
To connect devices (e.g. keyboard, scanner)
- E** *RS232 interface*
For serial transfer of print data
- F** *Status-LED/Ethernet*
- G** *Ethernet interface*
To connect to an „Ethernet 10/100 Base T“ network

- H** Optional: *Signal interface USI*
 - 4 inputs / 8 outputs
 - Standard at „64-xx Dispenser A“
- I** Optional: *Mini-DIN connector*
To connect an external operation panel
- J** Optional: *start/stop signal input*
 - Standard at 64-xx Dispenser
 - To connect a foot switch (signal starts printer) or a stacker (signal stops printer)
- K** *Centronics interface*
For parallel transfer of print data (cable is inclusive)
- L** *Power switch*
Turns the printer on/off
- M** *Mains power supply connector*
Connection to a mains socket using the provided power cable

Control panel (display)



[8] Control panel of the 64-xx.

Display With 32 digits and two lines, the display shows the operating conditions (modes) for parameters, values, status and errors. You can select the language you want to use for the display. Backlighting ensures good legibility.

Button functions The buttons offer a multitude of operating functions. A logical menu structure is used for operation. The meaning of each button varies according to the operating mode and the menu item. Additionally, special functions have been programmed for certain button combinations.


Depending on the modes and menu levels, the following functions apply for each button:

- Online button**
- For switching between online and offline mode.
 - For confirming entries, menu items and messages.
 - For selecting print jobs and for entering values in standalone mode.

- Cut button**
- Triggers a cut. Requirements:
 - Cutter fitted and activated.
 - Printer offline.
 - Also for accessing deeper levels within the menu structure and selecting menu items.
 - For decrementing values.

- Feed button**
- For feeding in material when the device is offline.
 - For starting the printing process once the feed has been stopped (in online mode).
 - Also for accessing deeper levels within the menu structure and selecting menu items.
 - Increments values.

- Prog button**
- For accessing the parameter menu when offline.
 - For stepping back through the parameter menu and/or exiting it.

- For more detailed descriptions of the button functions, please see
 - Chapter [Offline operation](#) / on page 11 and Chapter [Online operation](#) / on page 12
 - In topic section [Info-Printouts and Parameter](#) .

Operating modes

Offline mode

Printer settings can be made when the device is *offline*. The offline mode is normally active when the printer is switched on. Print jobs are received via the selected interface but not processed.

OFFLINE 0 JOBS No jobs are waiting to be processed.

To configure the printer so that it goes directly into online mode when switched on, set the parameter `SYSTEM PARAMETER > Active Mode` to “Online”.

Online mode

In *online* mode, print jobs are received and processed immediately. Possible messages:

ONLINE 0 JOBS No jobs are waiting to be processed.

ONLINE 0. JOBS The current data transfer to the printer is shown on the display. This is indicated by the dot on the bottom right next to the number of loaded jobs.

ONLINE 13 JOBS
Restcount: 25 During printing, the display also shows the number of print jobs read (13) and the remaining number of labels (25) to be printed in the current job.

ONLINE 13 JOBS
Restcount: endless If a print job recognises an endless number of labels to be printed, then the remaining number for this job is also shown as endless.

➡ To stop printing, press the online button.

Message mode

The printer uses status reports to signal an error or a particular operating status. This message mode indicates that the printer is waiting to quit or for fault clearance. When quitting, the printer switches from message mode to offline mode (depending on the error and the progress of the last active process).


Status 5001
No gap found Messages are made up of the status number and a brief descriptive text.

The status message 5001 (shown above) occurs when for example the printer is set for punched label material, but continuous form material without punches has been inserted. In this case, the printer will continue to feed the material for a few seconds before it generates an error message.

 [Status Reports](#): see topic section „Status Reports“.

Standalone mode

In standalone mode, print jobs are not transferred but saved on a plugin card. They are started directly from the printer’s control panel or via a connected keyboard.

 [Standalone mode](#): see topic section „Advanced Applications“.

Basic Operating Procedures

Connecting the printer




WARNING!

The printer operates using mains voltage! Touching electrically live parts can cause exposure to hazardous electrical currents and may lead to burns.

- Make sure that the printer is switched off before connecting the power cable.
- Only operate the printer using the system voltage indicated on the nameplate.
- Only connect the printer to a grounded power socket fitted to authorised standards.
- The power cable should be run to the printer so that
 - nobody will trip on it, and that
 - the power plug can easily be pulled out if necessary.

1. Ensure that the printer power switch is set to “0” (off).
2. Connect the printer to the power supply using the cable [9B] provided.
3. Using the data cable supplied, connect the Centronics interface [9A] on the printer to the host computer.



[9] Sockets for the Centronics cable (A) and power cable (B) on a 64-04

4. Turn on the printer using the power switch (set to position “1”). The following sequence of messages is displayed:

System start...	The boot loader is starting.
-----------------	------------------------------

System start...	Valid firmware recognised, program is starting.
Start user prog	

64-05	Printer type
V 4.10	Version number of the printer firmware

Memory: 64 MB
Flashcard: 32 MB

Internal RAM (here: 64 MB)
Optional RAM on the CompactFlash card (here: 32 MB) – only displayed when a CompactFlash card is in use.

OFFLINE 0 JOBS
Initialisation

Offline mode

ONLINE 0
JOBS

Online mode. The unit is ready for printing.

- ➡ When the parameter `SYSTEM PARAMETER > Active Mode` is set to “Offline”, the printer switches directly to offline mode when turned on.
- ➡ CAUTION! - Wait at least 10 seconds between switching the device off and on again, otherwise any modified parameter settings are not saved.

Setting the interface

By factory default, the 64-xx is set for data transfer via the Centronics interface. Print data can also be transferred via the RS232, USB or Ethernet interface.


- ➔ The interface type is selected with the following parameter:

`INTERF. PARAM. > EASYPLUGINTERPR > Interface`


- 📄 [Setting parameters](#): see topic section „Info-Printouts and Parameters“, chapter “Using the Parameter Menu”.
- 📄 [Data cables](#): Ordering numbers can be found in topic section „Accessories“.
- 📄 [Ethernet interface](#): Information about using it can be found in topic section „Advanced Applications“.

Offline operation

- Switching from offline mode to online mode:



- Switch to online mode when the print job is stopped:



- Slow material and ribbon feed:



- Material travels backwards under the printhead:




- Reset:



- Access the parameter menu:



- Feed material until the next punch is reached or as long as the button is held down:



- Standalone operation: Selecting a print job stored on a CF card (e.g., *Testdat.FOR*):



Online operation

- Switching to offline mode:



- Setting the print contrast: Press the Feed button to increase and the Cut button to decrease the print contrast.



- Interrupting the print job: The device will finish printing the current label.



a) The message "Stopped xxx" alternates with "Press Feed".

- Switching to offline mode while the print job is stopped:



- Continuing the print job:



- Standalone operation: Selecting a print job stored on a CF card (e.g., *Testdat.FOR*):



Creating a print job

Essentially, there are two ways of creating a print job: Either by using the 64-xx Windows printer driver, or by creating a text file using print commands.

Windows printer driver

64-xx printer drivers are available for different versions of Windows. You can print from nearly every Windows application using the printer drivers. However, functionality is strongly dependent on the choice of software. Special label layout programs are best suited, for example NiceLabel (a demo version is included with the printer shipment).

- ▣ The driver's help function explains how to use the printer driver. The help function of your Windows operating system will tell you how to install the driver.

▣ [Printer drivers](http://www.machines.averydennison.com/printersystems_gb.nsf/wview/L4L3?OpenDocument) for the different versions of Windows can be found on the Internet at (http://www.machines.averydennison.com/printersystems_gb.nsf/wview/L4L3?OpenDocument)

Command file

You can write a sequence of commands in a text file and send it to the printer. To do this, you can use any text editor and the MS-DOS Copy command. Easy Plug provides a special command language to program print jobs. However, writing a print job in text file format does require some programming knowledge. Furthermore, you will not be able to preview the resulting printout on the screen. Instead, you have to run a test print to see a copy of the finished result.

▣ [Easy Plug Manual](#): here you can find a practice example of a print job together with instructions in the section "Program Example" in topic section "General, Definitions Commands Overview".

Transferring a print job

The printer can only carry out a print job once this job has been transferred into the printer's RAM. This can be accomplished in two ways: via a direct transfer from your computer via a *data cable* or by saving it to a *Compact-Flash (CF) card*.

Data cable

The print job can be transferred

- via the serial interface,
- via the parallel interface, or
- via the Ethernet connection.

To transfer data via the serial or parallel interface, connect the corresponding ports on the host computer and the printer. Use the DOS window to send the print job file to the interface:

- Serial interface (COM1): `copy testjob.txt com1`
- Parallel interface (LPT1): `copy testjob.txt lpt1`
- USB interface / Ethernet interface:
`copy testjob.txt \\computername\sharename.`

– *computername* = Name of the computer (e.g., "DM-ECH-0990"). In Windows XP this can be found under START > SETTINGS > CONTROL PANEL > SYSTEM > COMPUTER NAME.

– *sharename* = enter the name found under START > SETTINGS > PRINTERS AND FAXES after clicking on a printer symbol and right-

clicking **PROPERTIES > SHARE** (in Windows XP). The sharename stands for a printer, which is connected to a certain port. This is the USB port for transferring via USB and the TCP/IP port for transferring by Ethernet.

A few hints on using the USB interface:

- ▣▣▣▣➔ The method described here does not work in Windows 98, Windows ME or Windows NT 4.0.
- ▣▣▣▣➔ The sharename has to comply with the MS-DOS formatting conventions (no more than 8 characters, no symbols or spaces).
- ▣ [Ethernet interface](#): Information about using it can be found in topic section „Advanced Applications“.
- ▣▣▣▣➔ Before sending a print job from a text program, you need to ensure that the correct printer driver has been installed.
- ▣▣▣▣➔ Special label layout programs, such as NiceLabel, make this much easier. These programs also require a driver to be installed.

CF card

You require the following items to load a print job from a CF card:

- CF card (copy the print job to the directory \FORMATS)
- CF card reader (to connect to your computer)
- ▣ [Transferring print jobs via CF card](#): A detailed description can be found in topic section „Advanced Applications“, chapter “Standalone Mode”.

Using CompactFlash cards


CF = CompactFlash



CAUTION! - Observe the following guidelines to avoid damaging the printer or the CF card.

- ➔ Only use CF -cards approved by the manufacturer.
- ➔ Always wait at least 5seconds after switching off the printer before removing or inserting the CF card.
- ➔ When inserting or removing the CF card, never use force.

- ▣ The printer firmware cannot utilise more than 128 MB of card storage capacity.



[10] Example: A 32 MB CF card


- ▣ **Suitable CF cards:** see Plugin-card manual, topic section „Card types“, chapter „CompactFlash card“.
- ▣ **Applying CF cards:** see Plugin-card manual, topic section „Application“, chapter „CompactFlash card“.

Inserting a CF card

1. Switch off the printer. Wait for 5 seconds.
2. Insert the CF card [11A] completely into the card slot, contact side first. The card's label is on the right side.
 - ▣ Push the CF card into the slot until the release button [11B] comes out. The inserted card will sit flush with the back wall of the housing.
 - ▣ The differently sized guide notches [10] of the CF card prevent the card from being inserted wrongly. For the card to be inserted correctly, the wider guide notch needs to be on top.

Removing a CF card

- ➔ Press the release button [11B] to remove the CF card.



[11] Inserting the CF card. If the CF card has been inserted correctly, it will sit flush with the printer's back wall (right).

Setting the realtime clock

The realtime clock in the 64-xx printers can be used, for example, to calculate and print the expiry date of a perishable product.

This is how you set the realtime clock:

1. Navigate to the `SYSTEM PARAMETER > Realtime Clock`.

Realtime clock
dd.mm.yyyy hh:mm

dd = day, mm = month, yyyy = year, hh = hour,
mm = minute

2. To enter the date and time, use the Cut button to shift the cursor, the Feed button to change the parameter, and the Online button to save it.

[Setting parameters](#): see topic section „Info-Printouts and Parameters“, chapter “Using the Parameter Menu”.

Outputting the realtime clock value using Easy Plug

Use the following Easy Plug commands to output the current realtime clock value:

- #YC realtime as text
- #YS realtime as barcode
- #DM download month names

[Easy Plug manual](#)

Starting to print

Settings for the material type

The parameter settings described below provide the printer with the necessary information about the label material used. When printing from a layout program, these settings are usually provided automatically by the printer driver. For your first test prints, you need to configure them manually.

- Material type**
- The label material is “endless”, which means that it contains *no* punches/perforations, breaks or reflex marks that could be recognised by the punch sensor:
→ Set the PRINT PARAMETER > Material Type to “endless”.
 - The label material contains punches/perforations, breaks or reflex marks that can be recognised by the punch sensor (so-called “punched” material):
→ Set the PRINT PARAMETER > Material Type to “Punched”.
- Material length** → Set the PRINT PARAMETER > Material Length to the length of the material (in mm).
- Material width** → Set the PRINT PARAMETER > Material Width to the width of the material (in mm).

Only for punched/perforated material:

- Type of punch**
- Label material with breaks or punches:
→ Set the SYSTEM PARAMETER > Sensor Type to “Punched”.
 - Label material with reflex marks:
→ Set the SYSTEM PARAMETER > Sensor Type to “Reflex”.
- 📖 [Setting parameters](#): see topic section „Info-Printouts and Parameters“, chapter “Using the Parameter Menu”.

Printing the status report

A status report printout is a perfectly adequate printer test. The width of the status printout can be set to 100 mm or 50 mm. This should match the width of the label material used. The length of the printout is 200 mm.

- 100 mm width** → Navigate to INFO PRINTOUT > Printer Status.
The printout that is triggered spans a label length of 2x 200 mm, listing all of the printer’s current parameter settings.
- 50 mm width** → Set the SYSTEM PARAMETER > Print Info Mode to “Compact right”.
→ Navigate to INFO PRINTOUT > Printer Status.
The printout that is triggered contains the same information as the wider printout, compressed to a width of 50 mm.
- Density**
- If the printout is not as black as you would like it to be, increase the print density as follows:
1. Press the Esc button while in online mode. Display:

Print contrast
60%
 2. By pressing the Cut/Feed buttons, you can increase or decrease the heat energy of the printhead (in %).

The heat energy should be kept as low as possible while retaining an acceptable printing result. A high level of heat energy reduces the lifespan of the printhead.